



July 2001
CONSUMER

10" TABLE SAW
Model F012340000

3400

open for tool illustration

Pos.	Part Number	Description {Qty}	F/C	Pos.	Part Number	Description {Qty}	F/C
1	2 610 358 924	Motor Housing	71	58	2 610 912 927	Pointer	9
2	2 610 909 424	Field 120V	22	59	2 610 912 928	Rip Fence Housing	9
3	2 610 905 924	Armature w/Fan 120V	AW	60	2 610 358 888	Rip Fence Body	9
4	2 610 912 921	Switch On/Off	15	61	2 610 358 887	Rear Sliding Pad	88
5	2 610 912 922	Cord	11	62	2 610 358 886	Spring	27
6	2 610 358 840	Strain Relief	11	63	2 610 358 885	Clamp	80
7	2 610 358 842	Cord Clamp	89	64	2 610 358 884	Rod	9
8	2 610 912 923	Nameplate	9	65	2 610 912 929	Miter Guage Handle	63
13	2 610 015 747	Ball Bearing	60	66	2 610 358 907	Washer	65
14	2 610 017 349	Ball Bearing	61	67	2 610 358 910	Miter Guage Body	9
19	2 610 358 841	Screw {2}	89	68	2 610 358 911	Pin	66
20	2 610 912 925	Label	9	69	2 610 358 913	Sliding Pad	88
22	2 610 358 803	Spacer {2}	82	70	2 610 358 832	Screw {9}	89
23	2 610 358 801	Washer	65	71	2 610 990 539	Screw	89
24	2 610 358 802	Washer {4}	65	72	2 610 913 860	Pointer	9
25	2 610 304 772	Nut {2}	89	73	2 610 912 930	Guide Bar	9
26	2 610 358 804	Rubber Pad	88	74	2 610 358 858	Arbor Nut	89
27	2 610 905 900	Bracket	9	75	2 610 358 857	Outer Flange	91
28	2 610 358 806	Pivot {2}	54	76	2 610 912 924	Base	9
29	2 610 358 807	Push Nut {4}	89	77	2 610 358 914	Shaft	52
30	2 610 358 800	Guard	91	78	2 610 358 915	Key	66
31	2 610 358 811	Pin	66	79	2 610 015 361	Ball Bearing	61
32	2 610 358 808	Anti-Kickback Pawl {2}	80	80	2 610 358 916	Retaining Ring	89
33	2 610 358 809	Spacer {2}	82	81	2 610 358 920	Screw & Washer {6}	89
34	2 610 912 939	Splitter	9	82	2 610 358 917	Bearing Cap	56
35	2 610 358 810	Spring	27	83	2 610 358 918	Bearing Housing	73
36	2 610 358 812	Roll Pin	66	84	2 610 358 919	Spindle Gear	32
37	2 610 358 813	Push Nut {2}	89	85	2 610 358 922	Needle Bearing	56
38	2 610 703 214	Screw	89	86	2 610 908 278	Gear Housing	72
39	2 610 910 013	Washer {2}	65	87	2 610 358 926	Screw {2}	89
40	2 610 912 936	Mounting Block	9	88	2 610 358 936	Washer {2}	65
41	2 610 358 819	Screw {2}	89	89	2 610 358 927	Washer	65
42	2 610 912 937	Bracket	9	90	2 610 358 928	Screw {3}	89
43	2 610 912 938	Clamp Plate	89	91	2 610 351 107	Nut {2}	89
44	2 610 912 941	Screw {3}	89	92	2 610 358 937	Brush Holder Pad {2}	25
45	2 610 998 580	Set Screw	89	93	2 610 358 935	Rear Motor Cover	70
46	2 610 912 926	Rip Fence Handle	74	94	2 610 358 932	Connector	10
47	2 610 044 563	Nut	89	95	2 610 909 438	Cable	10
48	2 610 358 895	Cam Pin	66	96	2 610 998 567	Strain Relief	11
49	2 610 358 896	Pin	66	97	2 610 358 822	Insert	9
50	2 610 358 894	Roll Pin	66	98	2 610 358 823	Screw {2}	89
51	2 610 910 017	Cam	80	99	2 610 358 824	Nut {2}	89
52	2 610 358 890	Lever	64	100	2 610 358 826	Screw {6}	89
53	2 610 358 891	Front Clamp	80	101	2 610 358 827	Screw	89
54	2 610 358 892	Screw {2}	89	102	2 610 358 828	Screw	89
55	2 610 358 898	Screw	89	103	2 610 912 931	Table	88
56	2 610 358 899	Spring	27	104	2 610 358 451	Scale	9
57	2 610 913 862	Screw	89	105	2 610 358 876	Nut {15}	89

+ = Not Illustrated * = As Required F/C = Failure Code AW = Refer to AW Labor Time Chart

Pos.	Part Number	Description {Qty}	F/C	Pos.	Part Number	Description {Qty}	F/C
106	2 610 358 867	Strap {2}	80	147	2 610 358 881	Pointer	9
107	2 610 912 935	Rod	5	148	2 610 990 549	Deflector Plate	9
108	2 610 903 744	Strap {4}	80	149	2 610 994 251	Spacer	82
109	2 610 905 904	Bracket	9	150	2 610 994 252	Bolt	89
110	2 610 358 863	Screw	89	151	2 610 358 902	Rail	9
111	2 610 358 865	Saddle	9	152	2 610 358 903	End Cap {2}	9
112	2 610 905 908	Screw {3}	89	153	2 610 905 909	Screw {4}	89
113	2 610 358 882	Roll Pin {2}	66	154	2 610 358 904	Spacer {4}	82
114	2 610 908 268	Screw {2}	89	155	2 610 911 896	Nut	89
115	2 610 908 270	Washer {2}	65	156	2 610 912 945	Mounting Post	9
116	2 610 908 271	Screw {2}	89	157	2 610 998 574	Screw	89
117	2 610 908 269	Support Bracket	62	158	2 610 997 243	Nut	89
118	2 610 990 544	Motor Bracket	62	159	2 610 912 946	Label {2}	9
119	2 610 910 044	Screw	89	650	2 610 912 940	Wrench	9
120	2 610 358 860	Screw {3}	89	651	2 610 996 880	Wrench	89
121	2 610 908 272	Nut {2}	89	753	2 610 080 093	Table Saw Stand	9
122	2 610 358 861	Screw {2}	89		w/pos. 753/6 - 753/10		
123	2 610 358 862	Spacer {2}	82	753/6	2 610 016 325	Bolt {24}	89
124	2 610 358 869	Retaining Ring	89	753/7	2 610 994 262	Nut {28}	89
125	2 610 901 978	Spacer	82	753/8	2 610 967 194	Bolt {4}	89
126	2 610 358 874	Rocker Bar	9	753/9	2 610 909 178	Washer {4}	65
127	2 610 358 877	Nut {2}	89	753/10	2 610 994 283	Foot {4}	9
128	2 610 358 878	Washer	65	754	2 610 080 099	Dust Bag Kit	9
129	2 610 358 879	Washer	65		w/pos. 754/2		
130	2 610 358 868	Pin	66	754/2	2 610 990 516	Dust Bag	9
131	2 610 990 545	Mounting Plate	62	756	2 610 080 089	Table Extension Kit	9
132	2 610 903 733	Spring	27		w/pos. 756/2 - 756/7		
133	2 610 912 932	Adjustment Wheel	63	756/2	2 610 351 293	Washer {6}	65
134	2 610 912 933	Knob	63	756/3	2 610 304 772	Nut {3}	89
135	2 610 990 547	Screw	89	756/4	2 610 702 414	Bolt {3}	89
136	2 610 358 833	Washer {2}	65	756/5	2 610 905 936	Bolt {3}	89
137	2 610 990 548	Handle Lock	80	756/6	2 610 911 906	Lock Washer {3}	65
138	2 610 358 844	Screw {3}	89	+ 756/7	2 610 994 273	Scale	9
139	2 610 910 018	Switch Cover	9	810	2 610 909 439	Brush & Holder Set	25
140	2 610 358 831	Clamp Plate	89	830	2 610 912 944	Blade Guard Assembly	92
141	2 610 358 846	Rubber Foot {4}	9		w/pos. 22 - 37, 142		
142	2 610 702 414	Screw	89	860	2 610 912 942	Rip Fence Assembly	87
143	2 610 912 934	Label	9		w/pos. 24, 41, 46 - 64		
144	2 610 358 830	Screw {4}	89	867	2 610 912 943	Miter Guage Assembly	87
145	2 610 306 005	Screw {3}	89		w/pos. 65 - 73		
146	2 610 026 248	Lock Washer {3}	89	N/A	Not Available Separately		

Service Notes:



